

P

PIERRE LANNIER


PARIS

1977

INSTRUCTION MANUAL 1977 WATCH

MAIN FEATURES :

- INITIATING THE PROCESS
- HOUR
- DATE



Your watch has a screw-down crown that allows it to remain water-resistant.

Watches with automatic movements wind themselves by the movement of the wrist.

The watch displays hours, minutes, seconds and date.

▪ Initiating the process :

Before wearing the watch or after a period of inactivity, it is necessary to wind it manually. To do this, hold the crown in the normal position and unscrew it by turning it downwards. You can now adjust your settings.

▪ Time and date setting :

Do not adjust between 10:00 pm and 2:00 am.

Pull the crown out to 1st position and turn it counterclockwise until the desired date is reached. Push the crown back in to complete the setting.

Pull the crown out to the 2nd position and turn it clockwise until the desired time is reached. Push the crown back in to complete the setting.

! At the end of your settings, remember to screw the crown back on to ensure that the watch remains water-resistant.

P
PIERRE LANNIER
PARIS



MKT 11.22